



Amrita Sai Institute of Science & Technology

Autonomous

Department of EEE

ENERGY AUDIT, CONSERVATION &
MANAGEMENT

UNIT-II
LIGHTING

Prepared by

K.SABARINATH

ASSISTANT PROFESSOR

UNIT-II LIGHTING

Light	It is defined as the radiant energy from a hot body that produces the visual sensation upon the human eye. It is expressed in lumen-hours and it analogous to watt hours, which denoted by the symbol 'Q'.
Color	The energy radiation of the heated body is monochromatic, i.e. the radiation of only one wavelength emits specific color. The wavelength of visible light lies between 4,000 and 7,500 Å.
Luminous flux	It is defined as the energy in the form of light waves radiated per second from a luminous body. It is represented by the symbol 'φ' and measured in Lumens
Plane Angle	A plane angle is the angle subtended at a point in a plane by two converging lines. It is denoted by the Greek letter 'θ' (theta) and is usually measured in degrees or radians $\therefore \text{Plane angle}(\theta) = \frac{\text{arc}}{\text{radius}}$
Solid angle	Solid angle is the angle subtended at a point in space by an area, i.e., the angle enclosed in the volume formed by numerous lines lying on the surface and meeting at the point. It is usually denoted by symbol 'ω' and is measured in steradian. $\therefore \text{Solid angle}(\omega) = \frac{\text{area}}{(\text{radius})^2}$
Luminous intensity	Luminous intensity in a given direction is defined as the luminous flux emitted by the source per unit solid angle. It is denoted by the symbol 'I' and is usually measured in 'candela'. Let 'F' be the luminous flux crossing a spherical segment of solid angle 'ω'. Then luminous intensity lumen/steradian or candela $\text{Luminous intensity } (I) = \frac{\phi}{\omega} \text{ lumen/steradian or candela.}$
Lumen	It is the unit of luminous flux. It is defined as the luminous flux emitted by a source of one candle power per unit solid angle in all directions. Lumen = CP × ω Total flux emitted by a source of one candle power is 4π lumens
Candle power (CP)	The CP of a source is defined as the total luminous flux lines emitted by that source in a unit solid angle.
Illumination	Illumination is defined as the luminous flux received by the surface per unit area. It is usually denoted by the symbol 'E' and is measured in lux or lumen/m ² or meter candle or foot candle.
Lux or meter candle	It is defined as the illumination of the inside of a sphere of radius 1 m and a source of 1 CP is fitted at the center of sphere.

Brightness	Brightness of any surface is defined as the luminous intensity per unit surface area of the projected surface in the given direction.
Mean horizontal candle power	MHCP is defined as the mean of the candle power of source in all directions in horizontal plane.
Mean spherical candle power	MSCP is defined as the mean of the candle power of source in all directions in all planes.
Mean hemispherical candle power	MHSCP is defined as the mean of the candle power of source in all directions above or below the horizontal plane.
Reduction factor	Reduction factor of the source of light is defined as the ratio of its mean spherical candle power to its mean horizontal candle power.
Lamp efficiency	It is defined as the ratio of the total luminous flux emitting from the source to its electrical power input in watts. $\therefore \text{Lamp efficiency} = \frac{\text{luminous flux}}{\text{power input}}$ It is expressed in lumen/W.
Specific consumption	It is defined as the ratio of electric power input to its average candle power.
Space to height ratio	It is defined as ratio of horizontal distance between adjacent lamps to the height of their mountings.
utilization factor	It is defined as the ratio of total number of lumens reaching the working plane to the total number of lumens emitting from source.
Maintenance factor	It is defined as the ratio of illumination under normal working conditions to the illumination when everything is clean.
Depreciation factor	It is defined as the ratio of initial illumination to the ultimate maintained illumination on the working plane. Its values is always more than 1.
Waste light factor	When a surface is illuminated by several numbers of the sources of light, there is certain amount of wastage due to overlapping of light waves; the wastage of light is taken into account depending upon the type of area to be illuminated.
Absorption factor	Normally, when the atmosphere is full of smoke and fumes, there is a possibility of absorption of light. Hence, the total lumens available after absorption to the total lumens emitted by the lamp are known as absorption factor
Reflection factor	When light rays impinge on a surface, it is reflected from the surface at an angle of incidence .

Introduction

Lighting is an essential service in all the industries. The power consumption by the industrial lighting varies between 2 to 10% of the total power depending on the type of industry. Innovation and continuous improvement in the field of lighting, has given rise to tremendous energy saving opportunities in this area.

Lighting is an area, which provides a major scope to achieve energy efficiency at the design stage, by incorporation of modern energy efficient lamps, luminaires and gears, apart from good operational practices.

Basic Terms in Lighting System and Features

Lamps

Lamp is equipment, which produces light. The most commonly used lamps are described briefly as follows:

- **Incandescent lamps:**

Incandescent lamps produce light by means of a filament heated to incandescence by the flow of electric current through it. The principal parts of an incandescent lamp, also known as GLS (General Lighting Service) lamp include the filament, the bulb, the fill gas and the cap.

- **Reflector lamps:**

Reflector lamps are basically incandescent, provided with a high quality internal mirror, which follows exactly the parabolic shape of the lamp. The reflector is resistant to corrosion, thus making the lamp maintenance free and output efficient.

- **Gas discharge lamps:**

The light from a gas discharge lamp is produced by the excitation of gas contained in either a tubular or elliptical outer bulb.

The most commonly used discharge lamps are as follows:

- Fluorescent tube lamps (FTL)
- Compact Fluorescent Lamps (CFL)
- Mercury Vapour Lamps
- Sodium Vapour Lamps
- Metal Halide Lamps

Luminaire

Luminaire is a device that distributes, filters or transforms the light emitted from one or more lamps. The luminaire includes, all the parts necessary for fixing and protecting the lamps, except the lamps themselves. In some cases, luminaires also include the necessary circuit auxiliaries, together with the means for connecting them to the electric supply. The basic physical principles used in optical luminaire are reflection, absorption, transmission and refraction.

Control Gear

The gears used in the lighting equipment are as follows:

- **Ballast:**

A current limiting device, to counter negative resistance characteristics of any discharge lamps. In case of fluorescent lamps, it aids the initial voltage build-up, required for starting.

- **Ignitors:**

These are used for starting high intensity Metal Halide and Sodium vapour lamps.

Illuminance

This is the quotient of the illuminous flux incident on an element of the surface at a point of surface containing the point, by the area of that element.

The lighting level produced by a lighting installation is usually qualified by the illuminance produced on a specified plane. In most cases, this plane is the major plane of the tasks in the interior and is commonly called the working plane. The illuminance provided by an installation affects both the performance of the tasks and the appearance of the space.

Lux (lx)

This is the illuminance produced by a luminous flux of one lumen, uniformly distributed over a surface area of one square metre. One lux is equal to one lumen per square meter.

Luminous Efficacy (lm/W)

This is the ratio of luminous flux emitted by a lamp to the power consumed by the lamp. It is a reflection of efficiency of energy conversion from electricity to light form.

Colour Rendering Index (RI)

Is a measure of the degree to which the colours of surfaces illuminated by a given light source confirm to those of the same surfaces under a reference illuminant; suitable allowance having been made for the state of Chromatic adaptation.

Lamp Types and their Features

The Table 8.1 shows the various types of lamp available along with their features.

LUMINOUS PERFORMANCE CHARACTERISTICS OF COMMONLY USED LUMINARIES					
Type of Lamp	Lumens / Watt		Color Rendering Index	Typical Application	Typical Life (hours)
	Range	Avg.			
Incandescent	8–18	14	Excellent	Homes, restaurants, general lighting, emergency lighting	1000
Fluorescent Lamps	46–60	50	Good w.r.t. coating	Offices, shops, hospitals, homes	5000
Compact fluorescent lamps (CFL)	40–70	60	Very good	Hotels, shops, homes,	8000–10000

				offices	
High pressure mercury (HPMV)	44–57	50	Fair	General lighting in factories, garages, car parking, flood lighting	5000
Halogen lamps	18–24	20	Excellent	Display, flood lighting, stadium exhibition grounds, construction areas	2000–4000
High pressure sodium (HPSV) SON	67–121	90	Fair	General lighting in factories, ware houses, street lighting	6000–12000
Low pressure sodium (LPSV) SOX	101–175	150	Poor	Roadways, tunnels, canals, street lighting	6000–12000

OPEN  BOX
EDUCATION

CONCEPTS

LAWS OF ILLUMINATION

Mainly there are two laws of illumination.

1. Inverse square law.
2. Lambert's cosine law.

Inverse square law

This law states that 'the illumination of a surface is inversely proportional to the square of distance between the surface and a point source'.




Fig.2.1 Inverse square law

Lambert's cosine law

This law states that 'illumination, E at any point on a surface is directly proportional to the cosine of the angle between the normal at that point and the line of flux'.




Fig.2.2 Lamberts Cosine Law

where d is the distance between the source and the surface in m, h is the height of source from the surface in m, and I is the luminous intensity in candela.

POLAR C
$$E_{zs} = \frac{I}{d^2} \cos \theta = \frac{I}{h^2} \cos^3 \theta$$

The luminous flux emitted by a source can be determined using the intensity distribution curve. The luminous intensity or the distribution of the light can be represented with the help of the polar curves. The polar curves are drawn by taking luminous intensities in various directions at an equal angular displacement in the sphere. A radial ordinate pointing in any particular direction on a polar curve represents the luminous intensity of the source when it is viewed from that direction. Accordingly, there are two different types of polar curves and they are:

1. A curve is plotted between the candle power and the angular position, if the luminous intensity, i.e., candle power is measured in the horizontal plane about the vertical axis, called 'horizontal polar curve'.
2. A curve is plotted between the candle power, if it is measured in the vertical plane and the angular position is known as 'vertical polar curve'. Figure shows the typical polar curves for an ordinary lamp.




Fig.2.3 Polar Curves

TYPES OF SOURCES OF ILLUMINATION

Usually in a broad sense, based upon the way of producing the light by electricity, the sources of light are classified into following four types.

Electric arc lamps

The ionization of air present between the two electrodes produces an arc and provides intense light.

Incandescent lamps


When the filaments of these lamps are heated to high temperature, they emit light that falls in the visible region of wavelength. Tungsten-filament lamps are operating on this principle.

Gaseous discharge lamps

When an electric current is made to pass through a gas or metal vapor, it produces visible radiation by discharge takes place in the gas vapor. Sodium and mercury vapor lamps operate on this principle.

Fluorescent lamps

Certain materials like phosphor powders exposed to ultraviolet rays emits the absorbed energy into visible radiations fall in the visible range of wavelength.



INCANDESCENT LAMP

These lamps are temperature-dependent sources. When electric current is made to flow through a fine metallic wire, which is known as filament, its temperature increases. At low temperatures, it emits only heat energy, but at very high temperature, the metallic wire emits both heat and light energy. These incandescent lamps are also known as temperature radiators.

Choice of material for filament

The materials commonly used as filament for incandescent lamps are carbon, tantalum, tungsten and osmium. The materials used for the filament of the incandescent lamp have the following properties.

- o The melting point of the filament material should be high.
- o The temperature coefficient of the material should be low.
- o It should be high resistive material.
- o The material should possess good mechanical strength to withstand vibrations.
- o The material should be ductile.

CONSTRUCTION :

Figure shows the construction of the pure tungsten filament incandescent lamp. It consists of an evacuated glass bulb and an aluminum or brass cap is provided with two pins to insert the bulb into the socket. The inner side of the bulb consists of a tungsten filament and the support wires are made of molybdenum to hold the filament in proper position. A glass button is provided in which the support wires are inserted




Fig.2.4 Incandescent lamp

OPERATION

When electric current is made to flow through the fine metallic tungsten filament, its temperature increases. At very high temperature, the filament emits both heat and light radiations, which fall in the visible region. The maximum temperature at which the filament can be worked without oxidization is $2,000^{\circ}\text{C}$, i.e., beyond this temperature, the tungsten filament blackens the inside of the bulb. The tungsten filament lamps can be operated efficiently beyond $2,000^{\circ}\text{C}$, it can be attained by inserting a small quantity of inert gas nitrogen with small quantity of organ. The variations in normal supply voltages will affect the operating characteristics of incandescent lamps.

SODIUM VAPOUR LAMP

A sodium vapor lamp is a cold cathode and low-pressure lamp. A sodium vapor discharge lamp consists of a *U*-shaped tube enclosed in a double-walled vacuum flask, to keep the temperature of the tube within the working region. The inner *U*-tube consists of two oxide-coated electrodes, which are sealed with the ends. These electrodes are connected to a pin type base construction of sodium vapour lamp is shown in Fig.




Fig. 2.5 Sodium vapor lamp

This sodium vapor lamp is low luminosity lamp, so that the length of the lamp should be more. In order to get the desired length, it is made in the form of a *U*-shaped tube. This long *U*-tube consists of a small amount of neon gas and metallic sodium. At the time of start, the neon gas vaporizes and develops sufficient heat to vaporize metallic sodium in the *U*-shaped tube.

WORKING

Initially, the sodium is in the form of a solid, deposited on the walls of inner tube. When sufficient voltage is impressed across the electrodes, the discharge starts in the inert gas, i.e., neon; it operates as a low-pressure neon lamp with pink color. The temperature of the lamp increases gradually and the

metallic sodium vaporizes and then ionizes thereby producing the monochromatic yellow light. This lamp takes 10–15 min to give its full light output. The yellowish output of the lamp makes the object appears gray.

FLUORESCENT LAMP (LOW-PRESSURE MERCURY VAPOR LAMP)

Fluorescent lamp is a hot cathode low-pressure mercury vapor lamp; the construction and working of the fluorescent lamp are explained as follows.

CONSTRUCTION

It consists of a long horizontal tube, due to low pressure maintained inside of the bulb; it is made in the form of a long tube. The tube consists of two spiral tungsten electrode coated with electron emissive material and are placed at the two edges of long tube. The tube contains small quantity of argon gas and certain amount of mercury, at a pressure of 2.5 mm of mercury. The construction of fluorescent lamp is shown in Fig. Normally, low-pressure mercury vapor lamps suffer from low efficiency and they produce an objectionable colored light. Such drawback is overcome by coating the inside of the tube with fluorescent powders. They are in the form of solids, which are usually known as phosphors.




Fig.2.6 Fluorescent Lamp

WORKING

At the time of starting, when both the lamp and the glow starters are cold, the mercury is in the form of globules. When supply is switched on, the glow starter terminals are open circuited and full supply voltage appeared across these terminals, due to low resistance of electrodes and choke coil. The small quantity of argon gas gets ionized, which establishes an arc with a starting glow. This glow warms up the bimetallic strip thus glow starts gets short circuited. Hence, the two electrodes come in series and are connected across the supply voltage. Now, the two electrodes get heated and start emitting

electrons due to the flow of current through them. These electrons collide with the argon atoms present in the long tube discharge that takes place through the argon gas

Stroboscopic effect

For 50-Hz frequency supply of the alternating current, a discharge lamp will be extinguished twice in a cycle and 100 times per second (for 50-Hz supply). A human eye cannot identify this extinguish phenomenon, because of the persistence of vision. If this light falls upon a moving object, the object appearing like slow moving or fast moving or moving in reverse direction, sometimes stationary. This effect is due to the extinguishing nature of the light of the lamp. This effect is called as '*stroboscopic effect*'.

TYPES OF LIGHTING SCHEMES

Usually, with the reflector and some special diffusing screens, it is possible to control the distribution of light emitted from lamps up to some extent. A good lighting scheme results in an attractive and commanding presence of objects and enhances the architectural style of the interior of a building. Depending upon the requirements and the way of light reaching the surface, lighting schemes are classified as follows:

1. Direct Lighting,
2. Semindirect Lighting,
3. Indirect Lighting,
4. Semi-Indirect Lighting, And
5. General Lighting.

1. Direct lightingschemes

Direct lighting scheme is most widely used for interior lighting scheme. In this scheme, by using deep reflectors, it is possible to make 90% of light falls just below the lamp. This scheme is more efficient but it suffers from hard shadows and glare. Hence, while designing such schemes, all the possibilities that will cause glare on the eye have to be eliminated. It is mainly used for industrial and general outdoor lighting

2. Semidirect lightingschemes

In semidirect lighting scheme, about 60–90% of lamps luminous flux is made to fall downward directly by using some reflectors and the rest of the light is used to illuminate the walls and ceiling. This type of light scheme is employed in rooms with high ceiling. Glare can be avoided by employing diffusing globes. This scheme will improve not only the brightness but also the efficiency.

3. Indirect lightingschemes

In this lighting scheme, 90% of total light is thrown upwards to the ceiling. In such scheme, the ceiling acts

as the lighting source and glare is reduced to minimum. This system provides shadowless illumination, which is very useful for drawing offices and in workshops where large machines and other difficulties would cause trouble some shadows if direct lighting schemes were used.

4. Semi-indirect lightingschemes

In semi-indirect lighting scheme, about 60–90% of light from the lamp is thrown upwards to the ceiling and the remaining luminous flux reaches the working surface. Glare will be completely eliminated with such type of lighting scheme. This scheme is widely preferred for indoor lighting decoration purpose.

5. General lightingscheme

This scheme of lighting use diffusing glasses to produce the equal illumination in all directions. Mounting height of the source should be much above eye level to avoid glare.




Fig.2.7.Types of Lighting Schemes

DESIGN OF LIGHTING SCHEMES

The lighting scheme should be such that:

- o It should be able to provide sufficient illumination.
- o It should be able to provide the uniform distribution of light throughout the working plane.
- o It should be able to produce the light of suitable color.
- o It should be able to avoid glare and hard shadows as much as possible.

While designing a lighting scheme, the following factors should be taken into consideration.

1. Illumination level.
2. The size of the room.
3. The mounting height and the space of fitting.

METHODS OF LIGHTING CALCULATIONS

There are so many methods have been employed for lighting calculation, some of those methods are as follows.

1. Watts-per-square-meter method.
2. Lumen or light flux method
3. Point-to-point method

STREET LIGHTING

Street lighting not only requires for shopping centers, promenades, etc. but also necessary for the following.

- o In order to make the street more attractive, so that obstructions on the road clearly visible to the drivers of vehicles.
- o To clear the traffic easily in order to promote safety and convenience.

The basic principles employed for the street lighting are given below.

1. Diffusion principle.
2. The specular reflection principle.

Diffusion Principle

In this method, light is directed downwards from the lamp by the suitably designed reflectors. The design of these reflectors are in such a way that they may reflect total light over the road surface uniformly as much as possible. The reflectors are made to have a cutoff between 30° and 45° , so that the filament of the lamp is not visible except just below the source, which results in eliminating glare.

Illumination at any point on the road surface is calculated by applying inverse square law or point-by-point method.

Specular Reflection Principle

The specular reflection principle enables a motorist to see an object about 30 m ahead. In this case, the reflectors are curved upwards, so that the light is thrown on the road at a very large angle of incidence. This can be explained with the help of Fig. An object resides over the road at 'P' in between the lamps S1, S2, and S3 and the observer at 'Q'.




Fig.2.8 Specular reflection for street lighting

Thus, the object will appear immediately against the bright road surface due to the lamps at a longer distance. This method of lighting is only suitable for straight sections along the road. In this method, it is observed that the objects on the roadway can be seen by a smaller expenditure of power than by the diffusion method of lighting.

Area Illumination (lumen/m²)

1. Road junctions and important shopping centers. 30
2. Poorly lighted sub-urban streets. 4
3. Average well-lighted street. 8–15

FLOOD LIGHTING

Floodlighting means flooding of large surface areas with light from powerful projectors. A special reflector and housing is employed in floodlighting in order to concentrate the light emitted from the lamp into a relatively narrow beam, which is known as floodlight projector. This projector consists of a reflecting surface that may be a silvered glass or chromium plate or stainless steel. The efficiency of silvered glass and polished metal are 85–90% and 70%, respectively. Usually metal reflectors are robust; therefore, they can be preferred. An important application of illumination engineering is the floodlighting of large and open areas. It is necessary to employ floodlighting to serve one or more of the following purposes.

Where flood lights are used

Flood lights are mostly used outdoors, but you will also see flood lights being used in larger indoor places, like arenas. The most common place, where people use flood lights is around the house. Flood lights are great outdoor lighting source and come in all sorts of sizes, from few watts to couple hundred watts. Flood lights are great to illuminate dark areas around the house at night for comfort and security purposes. It is common to use flood lights to provide light for security cams in dark, or to scare unwanted persons and animals away from backyard. Many people use flood lights to illuminate doors at night. In this situation, flood lights with motion sensor are used. Besides individual usage around the house, flood lights are also used in much larger areas. Some of these areas are:

- **Stadiums**
- **Sports fields**
- **Streets**
- **Driveways**
- **Parking lots**
- **Indoor and outdoor arenas**
- **Warehouses**

- **Many other large areas**

Flood light advantages compared to other lights

The closest type of lighting fixture to flood light is spot light. Spot lights are also used indoor and outdoor, but in opposite to flood lights, they have much smaller and concentrated range of light. Spot lights are great for illuminating one spot, but cannot be used to illuminate a whole area. High powered flood lights can provide close amount of light to daylight. For example, in some sports fields flood lights are arranged in such way that you have feeling that it's actually bright outside. Flood lights also are being used as work lights. Miners use flood lights to shed light into dark passages and caves they work in. Battery operated flood lights are used as emergency lights in places, where it's crucial to have permanent lighting source. Portable flood lights are also used by rescuers in disaster-prone areas, where other types of light sources are not available. As you can see, the advantages and usage of flood lights are practically unlimited, which makes them one of the most popular lighting source from small houses to arenas and other large areas.

Components of flood light fixtures

Flood light fixtures are pretty different from other types of light. First of all, flood lights are mostly used outdoors, so they need to be durable and withstand all sorts of weather conditions. There are special type of flood lights called outdoor flood lights that are made with durable metal (*usually aluminum*) casing and protects lighting fixture from high winds, rain, storms, high and low temperatures. There are also more basic flood light fixtures made for regular outdoor usage. These fixtures are made with less durable plastic casings, but also are able to withstand common weather conditions like rain, hot temperatures and even snow. Another common outdoor flood light type are solar flood lights that collect sun energy using a solar panel and stores it into a rechargeable battery and later at night uses this energy to power the light. As lighting source floodlights usually uses CFL, Halogen or LED bulbs. CFL flood lights are less common, because CFL bulbs are more brittle, with much larger form factor and have significantly shorter lifetime than, for example, LED bulbs. Halogen bulbs are the brightest ones, but have shorter lifetime than LED diodes. LEDs are the most popular type of bulbs used in flood light fixtures. Besides previously mentioned advantages, they also are the most energy efficient, so will cut more on electricity bills.

White light LED and conducting Polymers

A polymer LED is a type of OLED that uses polymers as a semiconducting material to produce very thin LEDs that can be used for many applications such as flexible displays, indoor lighting, and for medical technology applications such as light sources for lab-on-a-chip devices.

Polymer LEDs are produced by sandwiching electroluminescent polymers between a metal cathode and a transparent anode.

A polymer LED is also known as a PolyLED or a Light-Emitting Polymer (LEP).

Polymer LEDs have the advantage of being easily manufactured compared to traditional inorganic LEDs. An inorganic semiconductor has to be processed within a vacuum, and extreme care must be

taken in preparing materials for LEDs for wavelengths in the blue range. On the other hand, polymeric materials are very easy to process as they can be generated at ambient pressure through dip coating, rolling, spin coating and new inkjet fabrication methods that simply allow for printing of the polymer emitters into the substrate. Despite the distinct advantages of polymer LEDs, this is still a new technology that has many problems to work out, such as durability. For example, there is still color shift, particularly for blue, which degrades faster. The pixels themselves also have to be encapsulated from air to prevent degradation by oxygen, which takes away from their flexibility quite a bit.

Illumination of inclined surface to beam

At first, we examine a relation between the direction of incident electron beam and a sample orientation. There are following four cases (see Fig. 2.9) in terms of a specimen surface normal and a zone axis.

a) Both the specimen surface normal and the zone axis are parallel to the incident beam direction; b) and c) the specimen surface normal and the zone axis are respectively parallel to the incident beam direction; and

d) none of them is parallel to the incident beam direction. Most of the articles that treat the multislice formula assume the first case. Here, the inclined illumination corresponds to (c) to (d). For the electron microscopy the cases of (a) and (c) are important, because they are projections along a low index axes in a real space. In a diffraction experiment, however, an incident beam may be intentionally tilted away from a zone axis.

As an extension of a multislice formula for a normal illumination, even for an inclined illumination a specimen may be divided into slices perpendicular to the incident beam direction. However, some slices at top and bottom parts are not periodic perpendicular to the incident beam direction. Moreover, a large artificial period is required in many cases. A length of the artificial period becomes not acceptable for an infinitesimal tilt. It may be noted that no reflections produced by the artificial periodicity should give rise any intensity, because a period in a reciprocal space is determined by a real crystal lattice not by the artificial lattice. Therefore, this is an inefficient approach to calculate scattering intensities.




Fig. 2.9 Relations between an incident electron beam and a sample orientation.

Four cases are classified by a relation of an incident beam direction with an entrance surface normal and zone axis.

What is luminance?

Luminance is a measurement of the intensity of light emitted from a surface. It is objectively measured using “Candela per Square Meter” (cd/m²), which is the intensity per unit area in a specific direction.

During profiling, you can set different monitors to the same luminous intensity by choosing the same luminance in cd/m². Most LCD users find that setting luminance at **120** is bright enough to judge color and detail in highlights and shadows, but if you’re having a hard time seeing details try selecting a lower value. Some calibration programs offer an option to have the software automatically adjust your display’s luminance to match the ambient room light.

What is brightness?

Brightness is what we perceive when lumens fall on the rods and cones of our retina. When we speak of brightness, we use subjective words like “dim” or “brilliant” because it cannot be measured like luminance, but it can be scaled in percentages.

Many displays automatically adjust brightness and contrast based on the ambient light. You can also use the monitor’s manual controls to brighten or dim the screen based on your personal preference. Lowering the brightness value will result in a darker image, while raising the brightness will make it lighter.

ENERGY CONSERVATION MEASURE

An **Energy conservation measure** (ECM) is any type of project conducted, or technology implemented, to reduce the consumption of energy in a building. The types of projects implemented can be in a variety of forms but usually are designed to reduce utility costs: water, electricity and gas being the main three for industrial and commercial enterprises. The aim of an ECM should be to achieve a savings, reducing the amount of energy used by a particular process, technology or facility.

Energy conservation measures are often combined into larger guaranteed Energy Savings Performance Contracts to maximize energy savings while minimizing disruption to building occupants by coordinating renovations. Some ECMs cost less to implement yet return a higher energy savings. Traditionally, lighting projects were a good example of “low hanging fruit” that could be used to drive implementation of more substantial upgrades to HVAC systems in large facilities. Smaller buildings might combine window replacement with modern insulation using advanced building foams to improve energy for performance. Energy dashboard projects are a new kind of ECM which relies on the behavioral change of building occupants to save energy. When implemented as part of a program, case studies (such as that for the DC Schools) report

energy savings up to 30%. Under the right circumstances, open energy dashboards can even be implemented for free to improve upon these savings even more.

On a global basis energy efficiency works behind the scenes to improve our energy security, lower our energy bills and move us closer to reaching our climate goals. According to the IEA, some 40% of the global energy efficiency market is financed with debt and equity. Energy Performance Investment are one financing mechanism by which ECMs can be implemented now and paid for by the savings realized over the life of the project. While all 50 states, Puerto Rico and Washington, D.C., have statutes allowing companies to offer energy savings performance contracts, success varies because of variations in the approach, the state's degree of involvement and other factors. Homes and businesses are implementing energy-efficiency measures that include low-energy lighting, insulation and even high tech energy dashboards to cut bills by avoiding waste and boosting productivity.

Businesses implementing ECMs in their commercial buildings often employ Energy Service Companies (ESCOs) experienced in energy performance contracting. This industry has been around since the 1970s and is more prevalent than ever today. The US-based organization EVO (Efficiency Valuation Organization) has created a set of guidelines for ESCOs to adhere to in evaluating the savings achieved by ECMs. These guidelines are called the International Performance Measurement and Verification Protocol (IPMVP).

Homeowners implementing ECMs in their residential buildings often start with an energy audit. This is a way homeowners look at what areas of their homes are using, and possibly losing energy. Residential energy auditors are accredited by the Building Performance Institute (BPI)^[9] or the Residential Energy Services Network (RESNET). Homeowners can hire a professional or do it themselves or use a Smartphone to help do an audit